


# Gravel-O-Meter instruction manual



## Accessories

- Mini Hood Model x 1
- Protective acrylic panel x 1
- Power cord x 1
- Crushed stone for chipping test approx. 600g



Crushed stone for chipping test




Power cord

## Operating procedure

① Insert the mini hood model on the left side of the main unit.



② Please insert the protective acrylic panel inside the front panel.




③ Connect the power cord.



④ Press the red switch at the bottom of the front panel. Then, the lamp in the box will turn on.



⑤ Press the switch on the top right side of the box, and the motor will rotate.



Note: You can adjust the speed by turning the dial.

⑥ Put stones into the chute, they will be projected.

**Note: Be sure to insert the mini hood model first.**



Note: Remove the stones from the discharge tray after use.