








Heat Insulation Film Demonstration Tool Assembly Instructions


■ Parts / Accessories




■ Assemble according to the following order.




Fix aluminum frames on the base with screws.




Fix the top plate at the top of the aluminum frames with screws.




Screw in a halogen bulb in the bulb socket.



Insert the glass panels in the slit parts of the aluminum frames.



Install the top cover.



After connecting the power cord to the main body, plug it into an outlet and turn on the unit.

NOTE: Please remove the protective paper when using.

NOTE: For safety reasons, this product automatically shuts off 2 minutes after the power is turned on.

NOTE: Never touch the light bulb as it is very hot during lighting or immediately after it is turned off.

NOTE: If the accessory bulb burns out, replace it with a halogen beam lamp of "JDR110V50W / K12 / F / E26".